


ASSEMBLY PROCESS REMOTE CONTROL YCF50A REF. YC50-1518

A	PROVIDED IN THE KIT	Box remote control YCF50A		To be fixed onto the remote control bracket (B)
B	PROVIDED IN THE KIT	Remote control bracket YCF50A		To be fixed onto the rear frame part
C	ON YCF50A	CDI		To fix on C
D	ON YCF50A	Ignitor coil		D = Wire harness round steel part to be fixed onto the Ignitor coil. D= Connexion part to be fixed onto the Wire harness
E	PROVIDED IN THE KIT	Battery Cable RED (+) BLACK (-)	 A = B =	A (RED) to be screwed into the relay and fixed onto the Battery (+) B (BLACK) to be screwed onto the engine and fixed onto the (-).
F	ON YCF50A	Rectifier		To be fixed onto F
G	ON YCF50A	Battery 12V2.5A 50cc		E = A (BLACK) and B (RED) to be fixed onto the battery
H	ON YCF50A	Relay 50cc		To be fixed onto H (E / G / N / O to be screwed into the RELAY)
J	ON YCF50A	Kill switch YCF50A		To be fixed onto J
K	ON YCF50A	Start switch YCF50A		To be fixed onto K
L	ON YCF50A	Key contactor		To be fixed onto L
M	ON YCF50A	Stator (cable from engine)		To be fixed onto M
N	ON YCF50A	Charger connexion 50cc		To be fixed onto the relay and onto the engine




FIX THE REMOTE CONTROL BRACKET (B) ONTO THE REAR FRAME PART
THEN FIX THE BOX REMOTE CONTROL (A) ONTO THE BRACKET (B).



FOR YCF50A 2013 AND BEFORE, REPLACE THE WIRE HARNESS WITH THE ONE INCLUDED IN THE KIT.

FOR YCF50A 2014, KEEP THE WIRE HARNESS AS IT IS (NO NEED TO REPLACE IT).



FIX THE CABLES AGAINST THE REAR FRAME PART

FIX THE WIRE HARNESS ONTO THE FRAME

